



## PHOTOCENTRIC RESIN CLEANER INSTRUCTIONS

### USE INSTRUCTIONS

1. Place printed model in ultrasonic unit without heat for 2-4 minutes but no longer than 5 minutes.
2. Rinse model with clean water.
3. Place model in a container with water (40C-60C) under UV light for 2h (1h on each side). If using a Post Curing Unit, post processing should be 1h in water (40C-60C) under UV then 1h in Cure box at 80C or 2h at 60C

**Note:** Change cleaner when it no longer removes the stickiness from objects.

**IF ON SKIN,** Wash with plenty of water/soap and water.

**IF INHALED,** remove person to fresh air and keep at rest in a position comfortable for breathing.

**IF IN EYES,** rinse cautiously with water for several minutes. Remove contact lenses if present and easy to do so. Continue rinsing.

Material harmful if swallowed

Call a POISON CENTER or doctor if you feel unwell.

DO NOT dispose down the sink. Empty to a suitable container and dispose of according to local legislation

