

Elastic

DL160

PhotOcentric





Elastic DL160 is designed for applications where a high level of energy dampening, even at low temperatures (-24°C), is required. It displays elastomeric properties before break, rebound resilience of 10% (90% of energy is absorbed) and 70 Shore A hardness.

Optimised for Sportswear protection and 0 helmets at room and cold O Dampening rubbers and foams temperatures Cushioning Gaskets and seals

Unique features



Energy dampening even at cold temperature, glass transition temperature of -24°C






Elastomeric properties





Fast post curing



Good tear strength 20kN/m

Low water absorption (0.3%) potentially making it suitable for contact with the body during periods of high exertion

Elastic DL160 Translucent Properties Ö

Tensile Properites	Green	Post-Cured	Method
Tensile Modulus	1.48 MPa	13 MPa	ASTM D412
Ultimate Tensile Strength	0.98 MPa	12 MPa	ASTM D412
Tensile strength at 50% Elongation	-	2 MPa	ASTM D412
Tensile strength at 100% Elongation	-	4 MPa	ASTM D412
Elongation at Break	ТВС	162%	ASTM D412
Mechanical Properties		Post-Cured*	Method
Tear Strength		20 kN/m	ASTM 624
Rebound Resilience		10%	ASTM D7121
General Properties			
Shore Hardness		70 Shore A	ASTM D2240
Tg (DSC, S1 –57, S2 8)		-24 °C	Internal
Water absorption (%)* after 24 hrs		0.34%	ASTM D570
Water absorption (%)* after 72 hrs		0.38%	ASTM D570
Water absorption (%)* after 7 days		0.56%	ASTM D570
Viscosity		1100 cPs	At 25°C Brookfield spindle 3
Liquid density		1.04 g/cm3	-
Storage		10 <t<50°c< td=""><td>-</td></t<50°c<>	-

* Post cured for 2 hours at 60°C with Photocentric Cure L2

 \bigcirc



Elastic DL160 Black Properties

Tensile Properites	Green	Post-Cured	Method
Tensile Modulus	1.60 MPa	19.5 MPa	ASTM D412
Ultimate Tensile Strength	1.16 MPa	18.6 MPa	ASTM D412
Tensile strength at 50% Elongation	-	2.5 MPa	ASTM D412
Tensile strength at 100% Elongation	-	18 MPa	ASTM D412
Elongation at Break	86.4%	149%	ASTM D412
Mechanical Properties		Post-Cured*	Method
Tear Strength		23.2 kN/m	ASTM 624
Rebound Resilience		9.5%	ASTM D7121
General Properties			
Shore Hardness		74 Shore A	ASTM D2240
Tg (DSC, S1 –57, S2 8)		-24 °C	Internal
Water absorption (%)* after 24 hrs		0.29%	ASTM D570
Water absorption (%)* after 72 hrs		0.45%	ASTM D570
Water absorption (%)* after 7 days		0.62%	ASTM D570
Viscosity		1100 cPs	At 25°C Brookfiel spindle 3
Liquid density		1.04 g/cm3	-
		10 <t<50°c< td=""><td></td></t<50°c<>	

* Post cured for 2 hours at 60°C with Photocentric Cure L2





Design & Print Orientation Consideration Parameters

Properties	Parameters	
Minimum feature size (pins)	0.6mm	
Minimum hole diameter	1mm	
Minimum slot thickness	1.2mm	
Minimum wall thickness	0.5mm	
Overhangs	Successful for overhangs ≤45°	
Scaling factor	N/A (Photocentric Studio profiles reflect this value, no need for adjust- ment)	
Scaling factor for lattice structure with beam thickness ≤2mm	-4% XY and N/A Z (requires adjustment on Photocentric Studio profiles)	

Lattice Parameters

Photocentric applications team designed the following lattice test piece, as a recommendation for the user's first print with any flexible resin. By doing so, the user will understand the resin properties in relation to design parameters and assist them to design their next parts accordingly.

To download the file please click here.





Photocentric worked closely with General Lattice Frontier Software, a free-to-search material library of validated mechanical property data designed to support users in the selection of the best lattice, material, and hardware combination.

Elastic DL160 is one of the validated materials on Frontier library.

https://www.generallattice.com/frontier

Recommended orientations to print	45° angle or vertical as possible.
Recommended support structure to print	Depending on part size, choose a desired support profile in Photocentric Studio.



- To print with Photocentric Liquid Crystal Magna, choose Elastic DL160 Translucent at desired layer thickness when preparing your print file in Photocentric Studio.
- Heat the resin to 30°C in the bottle.



Post-Print Instructions

- 1. Parts can be washed in 'Photocentric Air Wash L' for 10-12 minutes using 'Photocentric Resin Cleaner 30'.
- 2. Make sure you do not exceed the recommended wash cycles as it might have an adverse effect on the mechanical properties.
- 3. Once washed, rinse with lukewarm water for 1-2 minutes. Parts can deform in hot/warm water.
- 4. Gently dry with compressed air to remove any remaining water. Or alternatively, leave to air-dry.
- 5. To reach the ultimate mechanical properties: Place the platform into the Photocentric Cure L2 for a minimum of 2 hours at 60°C.
- 6. Remove the platform from the Cure L2 and remove the part/s from the platform with using a scraper. It is easier to remove parts when they are still warm.