


Liquid Crystal MAGNA GUI ICONS

 Printer System Icon

-  Printer System is not ready
-  Printer System is launching
-  Printer System is up and running

 Wifi Icon

-  No Wi-Fi Connection
-  Strong Wi-Fi connection
-  Good Wi-Fi Connection
-  Weak Wi-Fi Connection
-  Poor Wi-Fi Connection

 IP: 192.168.20.121

Printer IP address appears when the printer is connected to a network. If no IP address is displayed, it means the printer is not connected to a network

 Door Switch Icon

The door switch safety feature provides safe printing operation for LC Magna. If the printer door is open, prints will not start, nor will the linear drive move.

-  Printer door is open
-  Printer door is closed

 Interlock Icon

Interlock in Magna compliments the door switch function to avoid opening the door during mechanical movements.

-  Interlock is disengaged
-  Interlock is engaged

 Print files

To navigate through to loaded files and initiate a print

 Maintain

To check and maintain printer features

 Network

To connect LC Magna to a Wi-Fi Network

 My Printer

Overview of Printer Capacity

 Sort

Function enables prints to be arranged alphabetically or by chronological upload order.

File(s) list

List of stored files available to print. Scroll up and down to see more. It is recommended that files are deleted after use to best utilise printer memory and retain processing memory for faster performance of the GUI.

 Refresh

Refresh button for file transfer so that files are visible on the list.

 Delete

Once selected, highlighted files can be deleted from the printer's memory.

 Main

Navigate back to "Main page"

 Re-home

LC Magna print platforms are factory calibrated in accordance with strict QC procedures prior to shipping. Please contact your supplier for information on re-homing should the need arise.

 Light on

The 'Light On' function will confirm that LC Magna's light engine is working properly. The light engine will illuminate behind the screen for 10 seconds.

 Clean

Cures a full layer of resin to assist with cleaning the resin vat.

 Pump

LC Magna works with patented peel release technology called Blow-Peel. We suggest testing the functionality of this feature weekly and immediately after a vat leak in accordance with maintenance schedule (Section 10). During this procedure, air will be pumped between the screen and vat film, causing the vat film to inflate. The vat film should remain inflated until the pump starts vacuuming the air out.

 Lift Platform

To lift the print platform to its homing location.

 Light OFF

Once you select 'Light On', you can turn it off by pressing 'Light Off'. Or, light will go off automatically after 10 seconds.

 Display

To check the printer screen function, select 'Test LCD'. Photocentric logo will be displayed in the centre of the screen.